

Neuro & Spine Powered Instruments

CORE™ Summex Drill

CORE Sumex Drill

5400-130-000PG CORE Sumex Drill

5400-131-000PG Sumex Handswitch



5400-130-000PG CORE Sumex Drill



5400-131-000 Sumex Handswitch


DuraGuards



12 mm	5400-210-057	Fixed
	5400-210-257	Steering
16 mm	5400-210-058	Fixed
	5400-210-258	Steering
25 mm	5400-210-059	Fixed
	5400-210-259	Steering



Tapered Router

For use with DuraGuards and D-Attachment			
Head Diameter (mm)	1.5	1.7	1.7
Head Length (mm)	12.0	16.0	25.0
DuraGuard Router	D-57 5400-071-057	D-58 5400-071-058	D-59 5400-071-059
5400-010-056 "D" Attachment			

*This does not replace the operative technique, please refer to the operative technique for all procedures. **Not drawn to scale.

Maestro Pneumatic Drill

Maestro Drills

5400-200-000PG 5400-201-000PG

Portmann Attachments

5100-120-044 5100-120-045

Irrigation Clips

5100-010-272 5100-010-270 5100-010-210 5100-010-200

Maestro Accessories

5400-006-000 5400-005-000 5400-279-000



5400-200-000PG Maestro Drill

5400-201-000PG Maestro Drill with Handswitch

DuraGuards



12 mm	5400-210-057	Fixed
	5400-210-257	Steering
16 mm	5400-210-058	Fixed
	5400-210-258	Steering
25 mm	5400-210-059	Fixed
	5400-210-259	Steering



Tapered Router

For use with DuraGuards and D-Attachment			
Head Diameter (mm)	1.5	1.7	1.7
Head Length (mm)	12.0	16.0	25.0
DuraGuard Router	D-57 5400-071-057	D-58 5400-071-058	D-59 5400-071-059

5400-010-056 "D" Attachment	
--------------------------------	--

*This does not replace the operative technique, please refer to the operative technique for all procedures. **Not drawn to scale.

SD/PD Series Attachments

SD/PD Series Attachments

5400-210-070	SD/PD Series Straight AM
5400-210-072	SD/PD Series Angled AM
5400-210-090	“RX” Extra Long Straight
5400-210-011	Right Angle Attachment
5400-210-050	SD/PD Series Straight M
5400-210-501	Adjustable Depth Drill Guide
5400-210-052	SD/PD Series Angled M
5400-210-020	SD/PD Series Straight O
5400-210-060	SD/PD Series Series Perforator Chuck
5100-060-001	Zyphr Perforator Bit

SD/PD Series Elite Attachments

5100-120-450	SD/PD Series Elite Medium Straight
5100-120-470	SD/PD Series Elite Long Straight
5100-120-480	SD/PD Series Elite Extra Long Straight
5100-120-490	SD/PD Series Elite Extra Long Plus Straight
5100-120-492	SD/PD Series Elite Extra Long Plus Angled
5100-120-482	SD/PD Series Elite Extra Long Angled
5100-120-472	SD/PD Series Elite Long Angled
5100-120-452	SD/PD Series Elite Medium Angled

*This does not replace the operative technique, please refer to the operative technique for all procedures. **Not drawn to scale.

CORE U Drill Attachments

CORE U & UHT Handswitches

- 5100-009-000 Handswitch
- 5400-111-000 UHT Handswitch



5100-009-000 Handswitch

U Series Elite Attachments

- 5100-010-450 U Series Elite Medium Elite Straight
- 5100-010-470 U Series Elite Long Elite Straight
- 5100-010-480 U Series Elite Extra Long Straight
- 5100-010-490 U Series Elite Extra Long Plus Straight
- 5100-010-482 U Series Elite Extra Long Elite Angled
- 5100-010-472 U Series Elite Long Elite Angled
- 5100-010-452 U Series Elite Medium Elite Angled



5400-111-000 UHT Handswitch




U Series Attachments

- 5100-010-072 "AM" Long Angled
- 5100-010-052 "M" Medium Angled
- 5100-010-022 "O" Short Angled
- 5100-010-020 "O" Short Straight
- 5100-010-050 "M" Medium Straight
- 5100-010-070 "AM" Long Straight
- 5100-010-080 "R" Long Straight
- 5100-010-090 "RX" Extra Long Straight
- 5100-010-501 Adjustable Depth Drill Guide
- 5100-010-011 Right Angle
- 5100-010-060 Perforator Chuck
- 5100-060-001 Zyphr Perforator Bit

DuraGuards

12 mm	5400-010-057	Fixed
	5400-010-257	Steering
16 mm	5400-010-058	Fixed
	5400-010-258	Steering
25 mm	5400-010-059	Fixed
	5400-010-259	Steering

Tapered Router

For use with DuraGuards and D-Attachment			
Head Diameter (mm)	1.5	1.7	1.7
Head Length (mm)	12.0	16.0	25.0
DuraGuard Router	D-57 5120-071-057	D-58 5120-071-058	D-59 5120-071-059

5400-010-056
"D" Attachment

*This does not replace the operative technique, please refer to the operative technique for all procedures. **Not drawn to scale.

MIS Attachments



SD/PD MIS Attachments

- 5100-120-920 SD/PD MIS Medium Straight
- 5100-120-950 SD/PD MIS Long Straight
- 5100-120-952 SD/PD MIS Long Curved
- 5100-120-922 SD/PD MIS Medium Curved

U Series MIS Attachments

- 5100-010-920 U Series MIS Medium Straight
- 5100-010-950 U Series MIS Long Straight
- 5100-010-952 U Series MIS Long Curved
- 5100-010-922 U Series MIS Medium Curved

*This does not replace the operative technique, please refer to the operative technique for all procedures. **Not drawn to scale.

Universal Driver

Drilling Attachments

- 4100-160-000 Trinkle Drill
- 4100-135-000 Hudson®/ Modified Trinkle Drill
- 4100-134-000 1/8" Keyless Drill
- 4100-133-000 1/4" Keyless Drill
- 4100-132-000 5/32" Keyed Drill Chuck
- 4100-131-000 1/4" Keyed Drill Chuck
- 4100-110-000 AO® Drill Attachment



5400-099-000* Universal Driver

4100-125-000

Pin Collet (Accepts pins from .078-.125" diameter)



4100-062-000

Wire Collet (Accepts wires from .028-.078" dia.)

*PG to add at the end of the code for the Polish & Greek manuals (for handpieces only)

*This does not replace the operative technique, please refer to the operative technique for all procedures. **Not drawn to scale.

The Bone Mill™

The Bone Mill™

- Blades designed for a uniform, consistent bone yield
- Different blade sizes allow for desired bone granulation
- Blades come preassembled for simple set up and operation
- Single pass cutting action enables uniform particulate size with low temperature bone exposure

- 5400-700-000** The Bone Mill™
- 5400-704-000** Bone Mill Handpiece Cable
- 5400-703-000** The Mill Disposable Coarse
- 5400-702-000** The Mill Disposable Fine
- 5400-701-000** The Mill Disposable Medium
- 5400-050-000** CORE Console
- 5400-705-000** Bone Mill Sterilisation Case



5400-700-000 The Bone Mill (used with 5400-050 CORE Console)

*This does not replace the operative technique, please refer to the operative technique for all procedures. **Not drawn to scale.

Powered Accessories

CORE Console



- 5400-050-000E** CORE Console with Integral Irrigation Pump
- 5400-050-001** CORE Irrigation Cassette 10/Pkg
- 5290-075-000** ESSx Irrigation Cassette 10/Pkg

- 5400-278-000**
CORE Sterilization Case - Large

Sterilization

- 5400-276-000** CORE Sterilization Case - Small
- 5400-277-000** CORE Sterilization Case - Medium
- 5400-278-000** CORE Sterilization Case - Large



Storage

A variety of storage units and labels are available for cutting accessory organization

- 5700-054-001** Saber Bur Rack
- 5700-054-002** Saber/Stapes Bur Rack
- 0298-098-100** Bur Organizer



- 5700-054-001** Saber Bur Rack

Footswitches

- 5100-008-000** Bi-Directional Footswitch
- 5100-007-000** Uni-Directional Footswitch
- 5400-007-000** NSE Footswitch